
EGT sensor instructions

The temperature indicated on your gauge is the temperature at the tip of your exhaust sensor. This temperature is different for each sleds on the market. An engine should never be tune by exhaust temperature alone. The exhaust gas temperatures are a great tuning aid but they are not the final word. The normal temperature range for most sleds will range between 593 °C and 676 °C depending on the engine set up. The temperature indicated should always be correlated with the piston and plug color Generally , probe location should be between 10 cm to 15 cm from the piston skirt out.

Each sled and exhaust systems manufacturer have their own specifications for probelocation and running temperature. To be more precise, these manufacturing companies should be contacted for all the details needed.



KOSO

70944 NO.406 DING-ANN ST. ANNAN DISTRICT TAINAN TAIWAN R.O.C
TEL +886-6-2556565 FAX +886-6-2461878
Http www.koso.com.tw
e-mail koso@url.com.tw / koso9981@ms34.hinet.net